


# Windows XP Installation Addendum

## Installing Software


When installing an *Actiontec* Wireless Adapter (PC Card, USB, or PCI) into a computer using the Windows XP operating system, follow the instructions below:

1. Ensure your computer is turned off.
2. Install the *Actiontec* Wireless Adapter hardware (see “Connecting Your *Actiontec* Wireless Adapter” in the user manual for instructions).
3. Turn your computer on.
4. Insert the Wireless Adapter Installation CD into your computer’s CD-ROM drive.
5. Windows XP detects the Wireless Adapter hardware, and the “Found New Hardware Wizard” screen appears.
6. Click **Next** to begin the Wireless Adapter software installation process.
7. A final screen wizard notifies you when the installation is finished. Click **Finish** to complete the process.
8. The “Wireless Connection” icon appears in the task bar tray (located on the lower right-hand side of your computer screen).

 **Note:** Installation of your Wireless Adapter does not automatically connect you to a wireless network. To connect, ensure there is a properly configured wireless router, access point, or computer in the vicinity, then proceed with the instructions on the following pages.

## Using Windows XP to Connect to a Wireless Network

To connect to a wireless network using Windows XP, follow the instructions below:


1. Right-click on the “Wireless Connection” icon  in the task bar tray (located at the lower right-hand corner of your computer screen).




2. Select **View Available Wireless Networks** from the menu that appears.



3. The “Connect to Wireless Network” window appears. In the **Available networks:** list box, choose the network you want to join, then click **Connect**.



 **Note:** When choosing a network from the **Available networks:** list box, both standard wireless networks (i.e., networks connected via a wireless router or access point) and ad hoc networks (computer-to-computer networks) will be listed, if available.

4. If the wireless network to which you want to connect requires an encryption key, enter the key in the **Network key:** text box.
  5. Click **Connect**. You are now connected to a wireless network.
5. Enter the network name in the **Network name (SSID):** text box.
  8. Click **OK**. In the “Connect to Wireless Network” window, choose the network you have just created. You have created a wireless ad hoc network. Other computers can now join your wireless ad hoc network.

## Using Windows XP to Create an Ad Hoc Network

To create an ad hoc (computer-to-computer) network using Windows XP:

1. Perform steps 1 and 2 from “Using Windows XP to Connect to a Wireless Network,” above.
2. When the “Connect to Wireless Network” window appears, click **Advanced**.
3. The “Wireless Networks Connection Properties” window appears. Select **Wireless Properties**.
4. In the “Preferred” section, click **Add...**
5. When the “Wireless Network Properties” window appears, click to activate the box next to **This is a computer-to-computer (ad hoc) network; wireless access points are not used**.

⇔ **Optional:** To disable Windows XP’s control of wireless networking, click **Advanced** in the “Connect to Wireless Network” window. When the “Wireless Network Connection Properties” window appears, uncheck the **Use Windows to configure my network settings** box at the top of the window. You can now use the *Actiontec* software tool to configure your wireless network (see “Configuring the *Actiontec* Wireless Adapter” in the user manual for more information).